




**Soldering Tips for SL-10 , SL-20 , SL-30 , SL-916, SL-916D,SL-928**

**Replacment Soldering Tip**



821	Conical	0.8	1/32
822	Conical	0.8	1/32
823	Conical	0.4	1/64
824	Screwdriver	1.6	1/16
825	Screwdriver	3.2	1/8
826	Screwdriver	1.2	3/64
827	Bent Screwdriver	1.6	1/16