

<p>PBS-17A-2 PUSH ON/PUSH OFF</p>		
<p>PBS-18B PUSH ON 25mA;50VAC or DC</p>		
<p>PBS-19B PUSH ON</p>		
<p>PBS-20A PUSH ON/PUSH OFF PBS-20B PUSH ON</p>		
<p>PBS-20A-2 PUSH ON/PUSH OFF PBS-20B-2 PUSH ON</p>		
<p>PBS-21A PUSH ON/PUSH OFF PBS-21B PUSH ON</p>		

<p>PBS-22A PUSH ON/PUSH OFF PBS-22B PUSH ON</p>		
<p>PBS-23B PUSH ON</p>		
<p>PBS-24-102P ON-ON PBS-24-112P ON-(ON) 2A 250VAC;4A 125VAC SPDT 3P (PC terminal) (L=14.2,11.8,9.8)</p>		
<p>PBS-24-202P ON-ON PBS-24-212P ON-(ON) 4A 125VAC;2A 250VAC DPDT 6P (PC terminal) (L=14.2,11.8,9.8)</p>		
<p>PBS-24-102 ON-ON PBS-24-112 ON-(ON) 4A 125VAC;2A 250VAC SPDT 3P</p>		
<p>PBS-24-202 ON-ON PBS-24-212 ON-(ON) 4A 125VAC;2A 250VAC</p>		