

# MPN3411 (SILICON)



• Can be used for AGC in T and Pi configurations.



CASE 226

#### MAXIMUM RATINGS

Rating	Symbol	Value	Unit Volts	
Reverse Voltage	VR	25		
Forward Power Dissipation @ $T_A = 25^{\circ}C$ Derate above $25^{\circ}C$	PF	400 4.0	mW mW/ <sup>0</sup> C	
Junction Temperature	Тj	+125	°C	
Storage Temperature Range	T <sub>stg</sub>	-65 to +150	°C	

### ELECTRICAL CHARACTERISTICS (T<sub>A</sub> = 25<sup>o</sup>C unless otherwise noted.)


Characteristic	Symbol	Min	Тур	Max	Unit
Reverse Breakdown Voltage $(I_R = 10 \mu A)$	V <sub>(BR)R</sub>	25	100		Volts
Diode Capacitance (Note 1) (V <sub>R</sub> = 20 Vdc, f = 100 MHz)	CT	-	-	0.45	pF
Forward Resistance MPN3411 (IF = 10 mA, f = 100 MHz) MPN3412	RF	- -	-	10 15	Ohms
Series Inductance (Note 2) (f = 250 MHz) (Measured at Lead Stop ≈ 1/8'')	LS	-	3.0	-	nH
Case Capacitance (f = 1.0 MHz)	СС	-	0.1		рF

NOTES


1  $C_{\mbox{T}}$  is measured using a capacitance bridge (Boonton Electronics Model 75A or equivalent).

 L<sub>S</sub> is measured on a package having a short instead of a die, using an impedance bridge (Boonton Radio Model 250A RX Meter).

## 819



## TYPICAL ELECTRICAL CHARACTERISTICS



ٽ 0.3

> 0.2 L 1.0

2.0 3.0 5.0

10

20 30 50

f, FREQUENCY (MHz)

FIGURE 4 - FORWARD RESISTANCE TEST METHOD

100

200 300 500

To measure forward resistance, a  $10\,pF$  capacitor is used to reduce the forward capacitance of the circuit and to prevent shorting of the external power supply through the bridge. The small signal from the bridge is prevented from shorting through the power supply by the 500-ohm resistor. The resistance of the  $10\,pF$  capacitor can be considered negligible for this measurement.

 The RF Admittance Bridge (Boonton 33A or B) must be initially balanced, with the test circuit connected to the bridge test terminals. The conductance scale will be set at zero and the capacitance scale will be set at 120 pF, as required when using the 100 MHz test coil.  Use a short length of wire to short the test circuit from point "A" to "B". Then connect the power supply providing 10 mA of bias current to the test circuit.

1000

- Adjust the capacitance scale arm of the bridge and the "G" zero control for a minimum null on the "null meter". The null occurs at approximately 130 pF.
- Replace the wire short with the device to be tested. Bias the device to a forward conductance state of 10 mA.
- Obtain a minimum null on the "null meter", with the capacitance and conductance scale adjustment arms.
- 6. Read conductance (G) direct from the scale. Now read the capacitance value from the scale ( $\approx 130 \text{ pF}$ ) and subtract 120 pF which yields capacitance (C). The forward resistance (R p) can now be calculated from:

$$R_F = \frac{KG}{C^2}$$

Where